


Gater Latch Assembly Instructions

Step 1.

Ensure you have all the parts ready for installation as per below image 1.



Step 2.

Insert cone spring with plastic retainer into narrow end of the latch.



Step 3.

Slide and lock in place plastic retainer. This holds spring in the correct location. Refer image 3 below.



Step 4.

Hold the plastic retainer in place with thumb.



Step 5.

Slide the latch onto the mounting bracket.



Step 6.

Gater latch is now ready for installation.

